



QUASAR SILENT PRO MENU MAP - MENU MODE=0 (STANDARD MENU)



QUASAR SILENT PRO MENU MAP - MENU MODE=1 (EXTENDED MENU)



QUASAR SILENT PRO MENU MAP - MENU MODE=1 (EXTENDED MENU)

NORMAL OPERATE

DISPLAY INTENSITY=0

POWER REDUCTION = 1

EEPROM ERROR

BUTTONS LOCKED

UNPLUG THE STROBE AND SEE THE MANUAL TO UNLOCK BUTTONS

TO BE CONTINUED FROM THE PREVIOUS PAGE

MODE SETTINGS MENU AS IT WAS SET LAST TIME

ANALOG

ANALOG EFFECT

2CH EFFECT

HF 2CH EFFECT

FIXTURE SETTINGS

INTENSITY (000-100)

INTENSITY (000-100)

DMX start addr. (001-511)

DMX start addr. (001-511)

POWER REDUCTION (0-1)

DURATION (002-250)

EFFECT SPEED (000-009)

DMX fan addr. (000-512)

DMX fan addr. (000-512)

DISPLAY INTENSITY (0-9)

REPEAT RATE (002-250)

EFFECT TYPE (1-6)

TURBO ON (0-1)

TURBO ON (0-1)

MENU MODE (0-1)

PRESS AT THE SAME TIME

FACTORY SETTINGS RESETED

Wait 3 sec. to operate

TURBO ON (0-1)

CONTINUOUS ON (0-1)

CONTINUOUS ON (0-1)

Wait 3 sec. to operate

CONTINUOUS ON (0-1)

Wait 3 sec. to operate

Wait 3 sec. to operate

Wait 3 sec. to operate

Wait 3 sec. to operate